

Procedure for Centrifuging BSL2 Agents with non-sealed rotors/buckets

1. RG2/BSL-2 samples will be prepared and loaded into rotors in the biosafety cabinet.
2. After the centrifugation run has ended, let the samples sit within the centrifuge for 5 minutes before removal.
3. Carefully open the lid to the centrifuge and check for any leaks or spills.
4. If a leak or spill has occurred, refer to Section 7.5 (Spills In Centrifuge) of the Biosafety Manual.